

READ INSTRUCTIONS CAREFULLY BEFORE BEGINNING CABINET ASSEMBLY. Retain instructions for future parts ordering.

## **Description**

Hallowell storage, wardrobe and combination cabinets are designed to provide secure storage for office supplies, books, tools, office machines, etc. in offices, schools, institutions, business and industrial store rooms.

The cabinet handle is supplied with a built-in lock and two keys. the cabinet has a three point locking system with lock bars located in nylon guides for quiet operation.

Model 815 is a storage cabinet that has four adjustable shelves for storage. Model 835 is a wardrobe cabinet with one hat shelf and a 36" coat rod. Model 855 is a combination wardrobe and storage cabinet with one hat shelf, an 18" coat rod and 4 adjustable 18" wide shelves.

## **Specifications**

Overall dimensions:

Model 815, 835, 855 are 78" high by 36" wide by 18" or 24" deep.

Basic construction:

Shelves, sides, rear, doors, top & bottom are 20 ga. steel. Frames are 16 ga. steel.

Approximate shipping weights:

 Model 815-S-18
 ....160 lbs.
 Model 815-S-24
 ....184 lbs.

 Model 835-W-18
 ....143 lbs.
 Model 835-W-24
 ....157 lbs.

 Model 855-C-18
 ....167 lbs.
 Model 855-C-24
 ....220 lbs.

Color: Parchment only, Shelf adjustment increments ....2"

## **ASSEMBLY INSTRUCTIONS**

(All Models)

Tools Required: 3/8" nut driver, slotted screwdriver, rubber mallet. Do NOT tighten bolts until cabinet is completely assembled.

- 1. Place rear panel (item 5) on either padded horses or on protected floor with flanges upward.
- 2. Attach side panels (items 7) with the flange under the rear panel offset with  $10-24 \times 3/8$ " bolts and nuts. The bottom support strips should be at the same end and shelf adjustment strips pointed in the same direction.
- 3. Place a shelf (item 8) into shelf adjustment strips to hold sides in upright position while attaching top (item 6).
- 4. Place door frame assembly (item 1 . 2 . 3) on top of assembly and bolt to top and side panels.
- 5. Position bottom (item 4) into offset support strips on sides and rear. Front flange of bottom must fit over front flange of frame and be bolted with 2 bolts from the outside (tighten).
- 6. If model 855, install center divider ( item 11 fig. 3 ) tighten bolt to bottom.
- 7. Bolt 4 cabinet foot braces (item 13) to frame and sides and rear (tighten). All models.
- 8. Stand cabinet upright, be sure cabinet is level and doors close properly then tighten all bolts.
- 9. Insert one side of adjustable shelf ( item 8 or 12 ) at desired position then move other side up to the same position. If model 835, bolt coat rod ( item 9 ) inside the flanges of shelf with bolt heads outward. Insert in top location. Seat all shelves with mallet.
- 10. Using rubber mallet tap nylon rod guide ( item 15 ) into top and bottom flanges of right door ( item 2 ).
- 11. Install locking handle ( item 24 ) to right door with #8-32 bolts ( item 19 ) see door handle detail. Place lock cam ( item 17 ) on back of handle with pins out. Insert lock rods ( item 16 ) into rod guides and position holes in lock rods on pins of lock cam. Secure in place with cam keeper (i tem 18 ) using 8-32 flat head screw ( item 20 ).

	hardware)	(standard	locally. (	ole	or (11- 11/1	* Included with handle PARCHMENT COLOR ONLY. MDS/CAS 1/6/94 * JMH	* Inc PARCI
			WITH TURNHANDLE		20 INCLUDED MBT200	8, 19, bolt N201	ITEM: 0 10- 0 10-
CH100A	CH100A	CH100A	CH100A	CH100A	CH100A	TURN HANDLE	21
					LT *	8-32 FL HD BOI	20
					.T *	8-32 RD HD BOLT	19
					*	CAM KEEPER	18
					*	LOCK CAM	17
ICLR78T	ICLR78T	ICLR78T	ICLR78T	ICLR78T	ICLR78T	LOCK ROD	16
LRG 1	LRG 1	LRG 1	LRG 1	LRG 1	LRG 1	ROD GUIDE	15
						COUNTER TOP	14
CFP100	CFP100	CFP100	CFP100	CFP100	CFP100	CABINET FOOT	13
ICAS1824	ICAS1818					18" SHELF	12
ICD2478	ICD1878				2	CENTER DIVIDER	11
ICCR18	ICCR18					18" COAT ROD	10
		ICCR36	ICCR36			36" COAT ROD	9
ICAS3624	ICAS3618	ICAS3624	ICAS3618	ICAS362	ICAS3618	36" SHELF	8
ICS2478F	ICS1878F	ICS2478F	ICS1878F	ICS2478F	ICS1878F	SIDE PANEL	7
ICT3624	ICT3618	ICT3624	ICT3618	ICT3624	ICT3618	TOP	6
ICR3678F	ICR3678F	ICR3678F	ICR3678F	ICR3678F	ICR3678F	REAR PANEL	5
ICB3624	ICB3618	ICB3624	ICB3618	ICB3624	ICB3618	BOTTOM	4
ICHFA78	ICHFA78	ICHFA78	ICHFA78	ICHFA78	ICHFA78	DOOR FRAME	ω
ICRD3678	ICRD3678	ICRD3678	ICRD3678	ICRD3678	ICRD3678	RIGHT DOOR	2
ICLD3678	ICLD3678	ICLD3678	ICLD3678	ICLD3678	ICLD3678	LEFT DOOR	Н
855-C-24	855-C-18	835-W-24	1835-W-18	815-S-24	815-S-18	DESCRIPTION	ITEM
855	MODEL 8	835	MODEL	L 815	MODEL		
	T PARTS	ABINE	HALLOWELL CABINET	MOT	HAI		

